

How to: Recalibrate the Mega Speed HHC touch screen.

1. Turn on the HHC by holding both red push buttons for 5 seconds. After 5 seconds stop pressing the right hand button.
2. Keep pressing and continue to hold the left side button that is labeled "LED On /Off" until the HHC screen goes black and 2 text lines appear which read:
"TSLIB calibration utility. Touch cross hair to calibrate."

It will take about 30 seconds for this screen to appear. Once it does you can let go of the red "LED" push button.

3. Now 5 separate cross hairs will appear, one at a time, starting on the top left. Use a soft plastic tip to do the calibration . Use a stylus or re-tracked , non metallic mechanical pencil tip.

The best method to do the calibration is to set your tip down outside of the current cross hair and then while applying gentle pressure slide the tip dead center into the cross hair and then lift up the tip. Once you release the pressure and remove the tip from the screen the calibration point will be saved.

Once the top left is done the cross hair will move clockwise around the screen going to the top right, bottom right, bottom left and at last to the center of the screen.

4. Once the fifth cross hair is set, the camera will now leave the calibration screen. Next hold down the right hand side " Start" button for 10 second to turn the camera off.

The calibration can be performed as many times as necessary. The camera will need to be rebooted after every calibration.

You have now calibrated your camera.